


MODEL TB1840

THIS TOOL EQUIPPED WITH
A RESTRICTIVE TRIGGER

SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



4/8/2009

SPOTNAILS MODEL TB1840

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70046	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24358	Cap Screw
07	P-32211	Flat Washer
08	P-60180	Cap
09	P-15193	Exhaust Seal
10	P-64384	O-Ring
11	P-18331	Poppet Spring
12	P-64232	Poppet O-Ring
13	P-63042	Poppet
14	P-64422	Piston Stop O-Ring
15	P-64467	Cylinder Seal O-Ring
16	P-03081	Guide Spacer
17	P-62079	Gasket
18	P-05106	Cylinder
19	P-64235	Cylinder O-Ring
20	P-64423	O-Ring
21	P-64424	Piston O-Ring
22	P-06239	Driver Blade
23	AS-06057	Piston & Driver Assembly
24	P-15121	Bumper
25	P-15122	Return Seal
26	P-01271	Body
27	P-64425	O-Ring
28	P-60175	End Cap
29	P-24300	Screw
30	AS-10052	Front Plate Assembly
31	P-07262	Pin
32	P-53165	Safety Guide
33	P-18328	Spring

Ref No.	Part No.	Description
34	AS-53057	Safety Assembly
35	P-15194	Valve Seal
36	P-18283	Spring
37	P-64390	O-Ring
38	P-22165	Plunger
39	P-22166	Valve Housing
40	P-64391	O-Ring
41	AS-21025	Restrictive Trigger Assembly
42	P-07327	Trigger Pin
43	P-24307	Screw
44	P-32170	Washer
45	P-13042	Bracket
46	P-24313	Screw
47	P-26126	Nut
48	P-07329	Retainer Pin
49	AS-12164	Magazine Assembly
50	P-12438	Feeder Cover
51	P-12439	Magazine Cover
52	P-24301	Screw
53	P-18234	Negator Spring
54	AS-09039	Pusher Assembly
55	P-18337	Spring
56	AS-21014	Bump Fire Trigger
57	P-15196	Driver Guide
58	P-64240	O-Ring
59	AS-53061	No Mar Tip Assembly
60	P-96129	No Mar Tip
61	P-32227	Washer
62	P-26165	Nut
63	P-07356	Pin
64	P-07353	Pin
65	AS-04036	Latch Assembly
66	P-64434	O-Ring

◆ Parts Included In AS- 97326 O-Ring And Seal Kit