


# MODEL TS6825S

# SPOTNAILS

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd  
Rolling Meadows, IL 60008  
Phone : 847-259-1620



4/24/2007

## SPOTNAILS MODEL TS6825S

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70046	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24358	Cap Screw
07	P-32211	Flat Washer
08	P-60180	Cap
◆	09	P-15193 Exhaust Seal
◆	10	P-64384 O-Ring
◆	11	P-18331 Poppet Spring
◆	12	P-64232 Poppet O-Ring
◆	13	P-63042 Poppet
◆	14	P-64422 Piston Stop O-Ring
◆	15	P-64467 Cylinder Seal O-Ring
◆	16	P-03081 Guide Spacer
◆	17	P-62079 Gasket
◆	18	P-05106 Cylinder
◆	19	P-64235 Cylinder O-Ring
◆	20	P-64423 O-Ring
◆	21	P-64424 Piston O-Ring
◆	22	P-06256 Driver Blade
◆	23	AS-06077 Piston & Driver Assembly
◆	24	P-15121 Bumper
◆	25	P-15161 Return Seal
◆	26	P-01271 Body
◆	27	P-64425 O-Ring
◆	28	P-60175 End Cap
◆	29	P-15214 Return Seal
◆	30	P-08495 Wear Plate
◆	31	P-24300 Screw

Ref No.	Part No.	Description
32	AS-10056	Front Plate Assembly
33	P-07262	Pin
34	P-53165	Safety Guide
35	P-18328	Spring
36	AS-53070	Safety Assembly
◆	37	P-64239 O-Ring
◆	38	P-22114 Bleeder Valve
◆	39	P-64241 O-Ring
◆	40	P-18227 Spring
◆	41	P-22179 Plunger
◆	42	P-64240 O-Ring
◆	43	AS-21014 Trigger Assembly
◆	44	P-07327 Trigger Pin
◆	45	P-18233 Spring Clip
◆	46	P-18232 Negator Spring
◆	47	P-12491 Magazine
◆	48	P-13078 Bracket
◆	49	P-32170 Washer
◆	50	P-24307 Screw
◆	51	AS-99085 Magazine Cover Assembly
◆	52	P-18454 Spring
◆	53	P-05107 Fixed Spacer
◆	54	P-24353 Screw
◆	55	P-09170 Pusher
◆	56	P-24370 Screw
◆	57	P-97476 String Guide
◆	58	P-24304 Screw
◆	59	P-64434 O-Ring
◆	60	P-07356 Step Pin
◆	61	P-07239 Pin
◆	62	AS-04037 Latch Assembly

◆ Parts Included In AS-97298 O-Ring And Seal Kit