

# MODEL WS4840LM

# SPOTNAILS®


DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd

Rolling Meadows, IL 60008

Phone : 847-259-1620

www.spotnails.com



## SPOTNAILS MODEL WS4840LM

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70042	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24300	Screw
07	P-32211	Flat Washer
08	P-60174	Cap
◆	09	P-15193 Exhaust Seal
◆	10	P-64384 O-Ring
◆	11	P-18331 Poppet Spring
◆	12	P-64385 Poppet O-Ring
◆	13	P-63038 Poppet
◆	14	P-64233 Piston Stop O-Ring
◆	15	P-64386 Cylinder Seal O-Ring
◆	16	P-03070 Guide Spacer
◆	17	P-62071 Gasket
◆	18	P-05097 Cylinder
◆	19	P-64387 Cylinder O-Ring
◆	20	P-64242 O-Ring
◆	21	P-64388 Piston O-Ring
◆	22	AS-06037 Piston & Driver Assembly
◆	23	P-15195 Bumper
◆	24	P-01261 Body
◆	25	P-64389 O-Ring
◆	26	P-60175 End Cap
◆	27	P-15196 Return Seal
◆	28	P-08465 Wear Plate
◆	29	P-24311 Screw

Ref No.	Part No.	Description
30	P-07290	Roll Pin
31	P-26125	Nut
32	AS-10045	Front Plate Assembly
33	P-24358	Screw
◆	38	P-64239 O-Ring
◆	39	P-64391 O-Ring
◆	42	AS-97269 Remote Valve
◆	47	P-13069 Bracket
◆	48	P-24358 Screw
◆	49	P-26126 Nut
◆	50	AS-99089 Magazine Cover Assembly
◆	51	P-05098 Fixed Spacer
◆	52	P-18488 Spring
◆	53	P-24489 Screw
◆	54	P-12482 Track
◆	55	P-24310 Screw
◆	56	P-18233 Spring Clip
◆	57	P-18481 Negator Spring
◆	58	P-09149 Pusher
◆	59	P-32144 Washer
◆	60	P-06228 Driver Blade
◆	61	P-07356 Step Pin
◆	62	P-07353 Spring Pin
◆	63	P-64434 O-Ring
◆	64	AS-04035 Latch Assembly
◆	65	P-13094 Bracket
◆	71	P-18493 Spring
◆	72	P-32245 Spacer

◆ Parts Included In AS-97373 O-Ring And Seal Kit