


MODEL WS4840 W

SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



SPOTNAILS MODEL WS4840W

Ref No.	Part No.	Description	
01	P-24370	Screw	
02	P-96118	Bushing	
03	P-70042	Exhaust Deflector	
04	P-64377	O-Ring	
05	P-32217	Washer	
06	P-24300	Screw	
07	P-32211	Flat Washer	
08	P-60174	Cap	
◆	09	P-15193	Exhaust Seal
◆	10	P-64384	O-Ring
	11	P-18331	Poppet Spring
◆	12	P-64385	Poppet O-Ring
	13	P-63038	Poppet
◆	14	P-64233	Piston Stop O-Ring
◆	15	P-64386	Cylinder Seal O-Ring
	16	P-03070	Guide Spacer
◆	17	P-62071	Gasket
	18	P-05097	Cylinder
◆	19	P-64387	Cylinder O-Ring
◆	20	P-64242	O-Ring
◆	21	P-64388	Piston O-Ring

Ref No.	Part No.	Description
22	AS-06037	Piston & Driver Assembly
23	P-15195	Bumper
24	P-01261	Body
25	P-64389	O-Ring
26	P-60175	End Cap
27	P-15196	Return Seal
28	P-08431	Wear Plate
29	P-26125	Nut
30	P-24307	Screw
31	P-24342	Screw
32	P-24311	Screw
33	P-07290	Roll Pin
34	P-10269	Front Plate
35	AS-99079	Flooring Attachment
36	P-24451	Nylon Screw
37	P-07291	Pin
38	P-53165	Safety Guide
39	P-18328	Spring
40	AS-53055	Safety Assembly
41	P-64240	O-Ring
42	P-07327	Trigger Pin

Ref No.	Part No.	Description
43	AS-21008	Trigger Assembly
44	P-15194	Valve Seal
45	P-18283	Spring
46	P-64390	O-Ring
47	P-22165	Plunger
48	P-22166	Valve Housing
49	P-64391	O-Ring
50	P-24309	Screw
51	P-12232	Track Cover
52	P-18233	Spring Clip
53	P-18232	Negator Spring
54	P-12231	Track
55	P-26124	Nut
56	P-32144	Washer
57	P-13069	Bracket
58	P-24306	Screw
59	P-03053	Spacer
60	P-24310	Screw
61	P-24319	Screw
62	P-09149	Pusher

◆ Parts Included In AS-97281 O-Ring And Seal Kit