


MODEL MT9764H

SPOTNAILS[®]

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
 Rolling Meadows, IL 60008
 Phone : 847-259-1620



SPOTNAILS MODEL MT9764H

Ref No.	Part No.	Description	Ref No.	Part No.	Description		
01	P-24370	Screw	37	P-22144	Trigger Valve Cap		
02	P-96118	Bushing	♦	38	P-64333	O-Ring	
03	P-70047	Exhaust Deflector	♦	39	P-64334	O-Ring	
04	P-64377	O-Ring	♦	40	P-64335	O-Ring	
05	P-24314	Cap Screw	41	P-22145	Pilot Valve		
06	P-32169	Flat Washer	♦	42	P-64336	O-Ring	
07	P-60181	Cap	43	P-18227	Spring		
♦	08	P-62080	Gasket	♦	44	P-64383	Plunger O-Rings
09	P-03076	Spacer	45	AS-22037	Swich Cover Set.		
10	P-15204	Exhaust Seal	♦	46	P-64328	O-Ring	
11	P-18442	Poppet Spring	♦	47	P-64240	O-Ring	
♦	12	P-64399	Poppet O-Ring	48	P-07327	Trigger Pin	
13	P-63043	Poppet	49	AS-21008	Trigger Assembly		
♦	14	P-64426	Poppet O-Ring	50	P-53165	Safety Guide	
♦	15	P-64312	Cylinder Seal O-Ring	51	P-18328	Spring	
16	P-03082	Guide Spacer	52	AS-53082	Safety Assembly		
17	P-24622	Screw	53	P-24385	Screw		
18	P-32303	Ring	54	P-24308	Screw		
19	P-03124	Spacer	55	P-32170	Washer		
♦	20	P-64427	Piston O-Ring	56	P-10310	Stationary Front Plate	
21	AS-06108	Piston & Driver Assembly	57	P-08493	Wear Plate		
♦	22	P-05130	Cylinder	58	P-24317	Screw	
♦	23	P-64401	Cylinder O-Ring	59	P-12481	Guide Nail Cover	
♦	24	P-64429	O-Ring	60	P-12369	Magazine(Right)	
25	P-15215	Bumper	61	P-13093	Bracket		
26	P-15200	Return Seal	62	P-26126	Nut		
27	P-01302	Body	63	P-24304	Screw		
28	P-64312	O-Ring	64	P-09165	Pusher		
29	P-60156	End Cap	65	P-18234	Negator Spring		
30	P-97454	Filter (Optional)	66	P-03056	Spacer		
31	P-07262	Pin	67	P-52036	Safety Yoke Guide		
♦	32	P-64430	O-Ring	68	P-10345	Removable Front Plate	
33	P-60220	Bottom Plate	69	P-08516	Nose		
34	P-32291	Washer	70	P-12370	Magazine(Left)		
35	P-24611	Screw	71	P-24319	Screw		
♦	36	P-64332	Valve Housing O-Ring				
	♦	Parts Included In AS-97383 O-Ring And Seal Kit					

3/25/2015

Parts Included In

O-Ring And Seal Kit