


MODEL SP2325

SPOTNAILS®
DIVISION OF PEACE INDUSTRIES, LTD.
1100 Hicks Rd
Rolling Meadows, IL 60008
Phone: 847-259-1620



SPOTNAILS MODEL SP2325 PARTS LIST

ITEM	PART NO.	DESCRIPTION
1	P-64366	O-Ring
2	P-63047	Poppet
3	P-64466	O-Ring Cylinder Seal
5	P-64369	Piston O-Ring
6	AS-06034	Driver Assembly
7	P-64370	O-Ring
8	P-64371	O-Ring
9	P-05094	Cylinder Spacer
10	P-05095	Cylinder
11	P-15183	Bumper
12	P-15184	Return Seal
13	P-70040	Deflector
14	P-15181	Seal Exhaust
15	P-18326	Spring Poppet
16	P-60169	Cap
17	P-64372	O-Ring
18	P-64375	O-Ring
19	P-01259	Body
20	P-97446	Handgrip
21	P-24311	Screw
22	P-24425	Screw
23	P-10282	Nose Cover

ITEM	PART NO.	DESCRIPTION
24	P-08462	Nose
25	P-15182	Valve Seal
26	P-22159	Plunger Guide
27	P-22160	Plunger
28	P-64373	O-Ring Plunger
29	P-64374	O-Ring Valve
30	P-22161	Valve Guide
31	P-18325	Spring Trigger
32	P-32208	E-Ring
33	P-07322	Roll Pin
34	P-21082	Trigger
35	P-64376	O-Ring End Cap
36	P-60170	End Cap
37	P-24311	Screw
38	P-24311	Screw
39	P-32207	Flat Washer
40	P-24309	Screw
41	P-13066	Latch Bracket
42	P-04061	Stopper
43	P-32209	Plate Washer
44	P-26125	Nut
45	P-96073	Pusher Nut
46	P-09182	Pusher

ITEM	PART NO.	DESCRIPTION
47	P-18320	Spring Stem
48	P-24303	Screw
49	P-18321	Pusher Spring
50	P-12399	Tail Cover
51	P-12400	Magazine Cover
52	P-26125	Nut
53	P-26155	Nut Plate
54	P-07323	Pin
55	P-10283	Left Magazine Plate
56	P-10284	Right Magazine Plate
57	P-07324	Adjusting Pin
58	P-18324	Spring
59	P-03068	Bushing
60	P-32210	E-Ring
61	P-32143	E-Ring
62	P-12401	Magazine
63	P-18323	Spring Stem
64	P-18322	Spring
65	P-26156	Screw Nut
66	P-97447	Adjust Plate
67	P-24385	Screw
68	P-24311	Screw