

# MODEL XS3640LM

# SPOTNAILS®


DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd

Rolling Meadows, IL 60008

Phone : 847-259-1620

www.spotnails.com



4/20/11

## SPOTNAILS MODEL XS3640LM

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70041	Exhaust Deflector
04	P-64377	O-Ring
05	P-24300	Cap Screw
06	P-32211	Flat Washer
07	P-60172	Cap
08	P-15187	Exhaust Seal
09	P-64378	O-Ring
10	P-18327	Poppet Spring
11	P-64028	Poppet O-Ring
12	P-63037	Poppet
13	P-64379	Piston Stop O-Ring
14	P-64380	Cylinder Seal O-Ring
15	P-03079	Guide Spacer
16	P-62070	Gasket
17	P-64228	Piston O-Ring
18	AS-06044	Piston & Driver Assembly
19	P-64330	Cylinder O-Ring
20	P-05096	Cylinder
21	P-64419	O-Ring
22	P-15197	Bumper
23	P-01263	Body
24	P-64312	O-Ring
25	P-60156	End Cap
26	P-07262	Pin
27	P-15203	Return Seal
28	P-24358	Screw
29	P-10285	Stationary Front Plate
30	P-07357	Step Pin
31	P-10289	Removable Front Plate
32	P-18333	Latch Spring
33	P-08472	Wear Plate
34	P-04062	Quick Clear Latch
35	P-53165	Safety Guide
36	P-18328	Spring
37	AS-53045	Safety Assembly

Ref No.	Part No.	Description
38	P-64332	Valve Housing O-Ring
39	P-22144	Trigger Valve Cap
40	P-64333	O-Ring
41	P-64334	O-Ring
42	P-64335	O-Ring
43	P-22145	Pilot Valve
44	P-64336	O-Ring
45	P-18227	Spring
46	P-64383	Plunger O-Rings
47	AS-22037	Plunger Assembly
49	P-64328	O-Ring
50	P-64240	O-Ring
51	P-07327	Trigger Pin
52	AS-21008	Trigger Assembly
53	P-26126	Nut
54	P-24430	Screw
55	P-24432	Screw
56	P-12563	Magazine Cover
57	P-07335	Negator Spring Pin
58	P-18556	Negator Spring
59	P-13070	Bracket
60	P-24301	Screw
61	P-26159	Nut Plate
62	P-24433	Screw
63	P-24434	Screw
65	P-12564	Magazine
66	P-07339	Pin
67	P-53167	Lathing Safety (Optional)
68	P-06223	Driver Blade
69	P-97454	Filter (Optional)
70	P-32107	Washer
71	AS-97296	Shingle Guide Assy. (Optional)
72	P-53175	Roofing Safety (Optional)
74	P-09213	Pusher
75	AS-99088	Wear Plate Filler
76	AS-21026	Restrictive Trigger Assembly (Optional)

◆ Parts Included In AS-97288 O-Ring And Seal Kit